


10. ADVANCED SETTINGS

Six advanced settings can be configured using the headset.

- Mute reminder tone
- Open phone line on undock
- Intellitone
- Wireless range
- Remote call control
- Wideband audio

10.1 CHANGE THE ADVANCED SETTINGS

1. Wear the headset, and simultaneously press and hold (5 secs) the volume buttons on the headset until you hear 'setup', and then release the buttons.
2. Tap the Multi-function button to cycle through the settings (see table below). Each setting will be announced in the headset. To change a setting, use the volume buttons to cycle through the setting values, and tap the Multi-function button to select the value.
3. When finished, simultaneously press and hold (5 secs) the volume buttons until you hear 'goodbye', then release the buttons. The base will reset and update the settings.



SETTING LIGHT	SETTING	VALUE LIGHT	VALUE
			Auto detect
			GN1000, RHL or none
	Remote call control		Jabra IQ
			DHSG
			MSH
			Optipoint
	Wideband audio		Off
			On



activate this